

**CHASSIS CURRENT RATING  
MUST NOT BE EXCEEDED**



Tach Calibration S2  0  100

Tach Select S1 AC  DC

S3 0-100 1 2 3 4 5 6 7 8 9

S4 0-90 1 2 3 4 5 6 7 8 9

1 2 3 4 5 6

• • • • • •

S5 0-700 S6 0-90 S7 0-9

S8 1 2 3 4 5 6 7 8

S9 1 2 3 4 5 6 7 8

Armature Calibration

1 Phase  1

45-65 Hz  2

3 Phase  3

Overcurrent  4

Trip  5

Run  6

Rotating  7

Health  8

Fault  Reset

Diagnostic Socket

7 8 9 10 11 12 13 14 15

• • • • • •

16 17 18 19 20 21 22 23 24

• • • • • •

25 26 27 28 29 30 31 32 33

• • • • • •

34 35 36 37 38 39

• • • • • •

P1 UP RATE

P2 DOWN RATE

P3 ZERO SPEED

P4 STAND STILL THRESH

P5 SPEED PROP

P6 SPEED INT.

P7 CURR. LIMIT

P8 CURR. PROP.

P9 CURR. INT.

P10 SPEED CAL

P11 FIELD VOLTS