Document Number:	7102	Keywords: Upgrade, Database	
Application Note		Product: ConfigEd, DSD	<u>3</u>

Objective

Upgrade Eurotherm DSD LINK to the latest version using the DSD LINK Manager software.

Equipment

Computer with DSD LINK and DSD LINK Manager software, modem and phone line.

Procedure

- 1. Launch LINK Manager on the computer. Refer to LINK Manager manual RG352101. Under SETTINGS::MODEM, make sure the phone number is 704-588-8713, in the DIAL block.
 - Note: If you are calling from a PBX system, you may have to add a 9 and a comma (,) in front of the telephone number; for example, AT DT 9, 7045888713.

Note: Also select the COMM PORT and BAUD RATE to match the computer hardware.

- 2. Click FILE::CLIENT; you should hear a dial tone and the computer should dial the LINK server. Also select the COMM PORT and BAUD RATE to match the computer hardware.
- 3. A window will appear as shown below. Click on the OK button. DSD LINK will automatically begin updating to the latest version.

oject Selection		
Local		Remote
Product Supp/Op Stations Cal Public/TIC TAC TOE		Product Supp/Op Stations Cal Public/TIC TAC TOE
	\longrightarrow	
	<< Read	
	<< Write	
Reset	<u>C</u> ancel	ОК

4. After the Link server is done downloading the updates it should log off and give you a message in the scratchpad stating "Normal Completion".

Note: If the scratchpad states "Abnormal Completion", repeat step number 3 until a "Normal Completion" appears.

5. Close the Manager program and launch ConfigEd. You will now have the newest version of ConfigEd.

Note: We recommend updating the DSD LINK database once every three months.

If you have questions, please call the Product Support Group at (704) 588-3246.

DRIVES