




**I 14 = RECZNY**  
**I 15 = AUTOMAT**  
**I 19 = KOSZ**



Creator:	LM	Project:	KRUSZARKA-24-6-23LM.lsc
Checked:		Installation:	
Date:	6/23/23 11:35 PM	File:	
		Customer:	
		Diagram No.:	1 / 6
		Page:	





Creator:	LM	Project:		Customer:	
Checked:		Installation:		Diagram No.:	
Date:	6/23/23 11:35 PM	File:	KRUSZARKA-24-6-23LM.lsc	Page:	3 / 6

Block Number (Type)	Parameter
B023(On-/Off-Delay) :	Rem = off 00:00s+ 00:00s
B024(On-/Off-Delay) :	Rem = off 00:00s+ 00:00s
B025(On-/Off-Delay) :	Rem = off 00:00s+ 00:00s
B026(On-/Off-Delay) :	Rem = off 00:00s+ 00:00s
B027(On-/Off-Delay) :	Rem = off 00:00s+ 00:00s
B028(On-/Off-Delay) :	Rem = off 00:00s+ 00:00s
B042(On-/Off-Delay) :	Rem = off 26:00s+ 00:00s
B043(On-/Off-Delay) :	Rem = off 24:00s+ 02:00s
B044(On-/Off-Delay) :	Rem = off 21:00s+ 05:00s
B045(On-/Off-Delay) :	Rem = off 18:00s+ 06:00s
B046(On-/Off-Delay) :	Rem = off 15:00s+ 07:00s
B047(On-/Off-Delay) :	Rem = off 12:00s+ 08:00s
B048(On-/Off-Delay) :	Rem = off 09:00s+ 09:00s
B049(On-/Off-Delay) :	Rem = off 06:00s+ 10:00s

Creator:	LM		Project:		Customer:	
Checked:			Installation:		Diagram No.:	
Date:	6/23/23 11:35 PM/6/23/23 11:52 PM		File:	KRUSZARKA-24-6-23LM.lsc	Page:	4 / 6

Block Number (Type)	Parameter
B050(On-/Off-Delay) :	Rem = off 03:00s+ 11:00s
B051(On-/Off-Delay) :	Rem = off 00:00s+ 20:00s
B066(Wiping relay (pulse output)) :	Rem = off 30:00s+
B099(Asynchronous Pulse Generator) :	Rem = off 00:50s+ 00:50s

Creator:	LM		Project:		Customer:	
Checked:			Installation:		Diagram No.:	
Date:	6/23/23 11:35 PM/6/23/23 11:52 PM		File:	KRUSZARKA-24-6-23LM.lsc	Page:	5 / 6

Connection	Label
I1	
I2	
I3	
I4	
I5	
I6	
I7	
I8	
I9	
I10	
I13	
I14	
I17	
I18	
I19	
I20	
I21	
I22	
I23	
I24	
Q1	
Q2	
Q3	
Q4	
Q5	
Q6	
Q7	
Q8	
Q9	
Q10	
Q11	

--	--	--	--	--	--

Creator:	LM		Project:		Customer:	
Checked:			Installation:		Diagram No.:	
Date:	6/23/23 11:35 PM/6/23/23 11:52 PM		File:	KRUSZARKA-24-6-23LM.lsc	Page:	6 / 6